



# VERTEC VT4889 V4 PRESETS

## XTA DP448

						INPUT A	INPUT B	INPUT C	INPUT D	
3-WAY STEREO + AUX		PRESET	OUT 1	OUT 2	OUT 3	OUT 4	OUT 5	OUT 6	OUT 7	OUT 8
VT4889 3WX		257	AUX (FULLRANGE)	4889 LOW	4889 MID	4889 HI	AUX (FULLRANGE)	4889 LOW	4889 MID	4889 HI
4-WAY STEREO		PRESET	OUT 1	OUT 2	OUT 3	OUT 4	OUT 5	OUT 6	OUT 7	OUT 8
4889 4881A X		258	4881A	4889 LOW	4889 MID	4889 HI	4881A	4889 LOW	4889 MID	4889 HI
4889 4881A 60		259	4881A	4889 LOW	4889 MID	4889 HI	4881A	4889 LOW	4889 MID	4889 HI
4889 4881A 80		260	4881A	4889 LOW	4889 MID	4889 HI	4881A	4889 LOW	4889 MID	4889 HI
4889 4882 X		261	4882	4889 LOW	4889 MID	4889 HI	4882	4889 LOW	4889 MID	4889 HI
4889 4882 60		262	4882	4889 LOW	4889 MID	4889 HI	4882	4889 LOW	4889 MID	4889 HI
4889 4882 80		263	4882	4889 LOW	4889 MID	4889 HI	4882	4889 LOW	4889 MID	4889 HI
4889 4880 X		264	4880	4889 LOW	4889 MID	4889 HI	4880	4889 LOW	4889 MID	4889 HI
4889 4880 60		265	4880	4889 LOW	4889 MID	4889 HI	4880	4889 LOW	4889 MID	4889 HI
4889 4880 80		266	4880	4889 LOW	4889 MID	4889 HI	4880	4889 LOW	4889 MID	4889 HI
4889 4880A X		267	4880A	4889 LOW	4889 MID	4889 HI	4880A	4889 LOW	4889 MID	4889 HI
4889 4880A 60		268	4880A	4889 LOW	4889 MID	4889 HI	4880A	4889 LOW	4889 MID	4889 HI
4889 4880A 80		269	4880A	4889 LOW	4889 MID	4889 HI	4880A	4889 LOW	4889 MID	4889 HI
4-WAY / AUX SUB + 3-WAY		PRESET	OUT 1	OUT 2	OUT 3	OUT 4	OUT 5	OUT 6	OUT 7	OUT 8
89 / 80 + 80 X + 89		270	4880	4880	4889 LOW	4889 MID	4889 HI	4889 3WX LOW	4889 3WX MID	4889 3WX HI
89 / 80 + 80 60 + 89		271	4880	4880	4889 LOW	4889 MID	4889 HI	4889 3WX LOW	4889 3WX MID	4889 3WX HI
89 / 80 + 80 80 + 89		272	4880	4880	4889 LOW	4889 MID	4889 HI	4889 3WX LOW	4889 3WX MID	4889 3WX HI
89 / 80A + 80A X + 89		273	4880A	4880A	4889 LOW	4889 MID	4889 HI	4889 3WX LOW	4889 3WX MID	4889 3WX HI
89 / 80A + 80A 60 + 89		274	4880A	4880A	4889 LOW	4889 MID	4889 HI	4889 3WX LOW	4889 3WX MID	4889 3WX HI
89 / 80A + 80A 80 + 89		275	4880A	4880A	4889 LOW	4889 MID	4889 HI	4889 3WX LOW	4889 3WX MID	4889 3WX HI
89 / 80 + 80 X + 88		276	4880	4880	4889 LOW	4889 MID	4889 HI	4888 3WX LOW	4888 3WX MID	4888 3WX HI
89 / 80 + 80 60 + 88		277	4880	4880	4889 LOW	4889 MID	4889 HI	4888 3WX LOW	4888 3WX MID	4888 3WX HI
89 / 80 + 80 80 + 88		278	4880	4880	4889 LOW	4889 MID	4889 HI	4888 3WX LOW	4888 3WX MID	4888 3WX HI
89 / 80A + 80A X + 88		279	4880A	4880A	4889 LOW	4889 MID	4889 HI	4888 3WX LOW	4888 3WX MID	4888 3WX HI
89 / 80A + 80A 60 + 88		280	4880A	4880A	4889 LOW	4889 MID	4889 HI	4888 3WX LOW	4888 3WX MID	4888 3WX HI
89 / 80A + 80A 80 + 88		281	4880A	4880A	4889 LOW	4889 MID	4889 HI	4888 3WX LOW	4888 3WX MID	4888 3WX HI
4-WAY + DOWN (DF) / OFFSTAGE FILL (2WX)		PRESET	OUT 1	OUT 2	OUT 3	OUT 4	OUT 5	OUT 6	OUT 7	OUT 8
89 / 87 + 80 X + 87		282	4880	4889 LOW	4889 MID	4889 HI	4887 DF LO	4887 DF MH	4887 2WX LO	4887 2WX MH
89 / 87 + 80 60 + 87		283	4880	4889 LOW	4889 MID	4889 HI	4887 DF LO	4887 DF MH	4887 2WX LO	4887 2WX MH
89 / 87 + 80 80 + 87		284	4880	4889 LOW	4889 MID	4889 HI	4887 DF LO	4887 DF MH	4887 2WX LO	4887 2WX MH
89 / 87 + 80A X + 87		285	4880A	4889 LOW	4889 MID	4889 HI	4887 DF LO	4887 DF MH	4887 2WX LO	4887 2WX MH
89 / 87 + 80A 60 + 87		286	4880A	4889 LOW	4889 MID	4889 HI	4887 DF LO	4887 DF MH	4887 2WX LO	4887 2WX MH
89 / 87 + 80A 80 + 87		287	4880A	4889 LOW	4889 MID	4889 HI	4887 DF LO	4887 DF MH	4887 2WX LO	4887 2WX MH
89 / 87A + 80 X + 87A		288	4880	4889 LOW	4889 MID	4889 HI	4887A DF LO	4887A DF MH	4887A 2WX LO	4887A 2WX MH
89 / 87A + 80 60 + 87A		289	4880	4889 LOW	4889 MID	4889 HI	4887A DF LO	4887A DF MH	4887A 2WX LO	4887A 2WX MH
89 / 87A + 80 80 + 87A		290	4880	4889 LOW	4889 MID	4889 HI	4887A DF LO	4887A DF MH	4887A 2WX LO	4887A 2WX MH
89 / 87A + 80A X + 87A		291	4880A	4889 LOW	4889 MID	4889 HI	4887A DF LO	4887A DF MH	4887A 2WX LO	4887A 2WX MH
89 / 87A + 80A 60 + 87A		292	4880A	4889 LOW	4889 MID	4889 HI	4887A DF LO	4887A DF MH	4887A 2WX LO	4887A 2WX MH
89 / 87A + 80A 80 + 87A		293	4880A	4889 LOW	4889 MID	4889 HI	4887A DF LO	4887A DF MH	4887A 2WX LO	4887A 2WX MH
4-WAY + DOWN (DF) / DISTRIBUTED FILL (2W)		PRESET	OUT 1	OUT 2	OUT 3	OUT 4	OUT 5	OUT 6	OUT 7	OUT 8
89 / 87 + 80 X + 87 F		294	4880	4889 LOW	4889 MID	4889 HI	4887 DF LO	4887 DF MH	4887 2W LO	4887 2W MH
89 / 87 + 80 60 + 87 F		295	4880	4889 LOW	4889 MID	4889 HI	4887 DF LO	4887 DF MH	4887 2W LO	4887 2W MH
89 / 87 + 80 80 + 87 F		296	4880	4889 LOW	4889 MID	4889 HI	4887 DF LO	4887 DF MH	4887 2W LO	4887 2W MH
89 / 87 + 80A X + 87 F		297	4880A	4889 LOW	4889 MID	4889 HI	4887 DF LO	4887 DF MH	4887 2W LO	4887 2W MH
89 / 87 + 80A 60 + 87 F		298	4880A	4889 LOW	4889 MID	4889 HI	4887 DF LO	4887 DF MH	4887 2W LO	4887 2W MH
89 / 87 + 80A 80 + 87 F		299	4880A	4889 LOW	4889 MID	4889 HI	4887 DF LO	4887 DF MH	4887 2W LO	4887 2W MH
89 / 87A + 80 X + 87A F		300	4880	4889 LOW	4889 MID	4889 HI	4887A DF LO	4887A DF MH	4887A 2W LO	4887A 2W MH
89 / 87A + 80 60 + 87A F		301	4880	4889 LOW	4889 MID	4889 HI	4887A DF LO	4887A DF MH	4887A 2W LO	4887A 2W MH
89 / 87A + 80 80 + 87A F		302	4880	4889 LOW	4889 MID	4889 HI	4887A DF LO	4887A DF MH	4887A 2W LO	4887A 2W MH
89 / 87A + 80A X + 87A F		303	4880A	4889 LOW	4889 MID	4889 HI	4887A DF LO	4887A DF MH	4887A 2W LO	4887A 2W MH
89 / 87A + 80A 60 + 87A F		304	4880A	4889 LOW	4889 MID	4889 HI	4887A DF LO	4887A DF MH	4887A 2W LO	4887A 2W MH
89 / 87A + 80A 80 + 87A F		305	4880A	4889 LOW	4889 MID	4889 HI	4887A DF LO	4887A DF MH	4887A 2W LO	4887A 2W MH

## NOTES:

Preset 257	Stereo 3-Way with AUX / FULLRANGE Outputs (flat, gain at -infinity)
Presets 258-269	Stereo 4-Way Presets (X, 60, 80 sub/low processing)
Presets 270-275	4-Way (AUX SUB DRIVE OPTION or FLOWN/GROUND STACKED SUBS) + 4889 3WX
Presets 276-281	4-Way (AUX SUB DRIVE OPTION or FLOWN/GROUND STACKED SUBS) + 4888 3WX
Presets 282-287	4-Way + DOWNFILL (4887 DF) + OFFSTAGE FILL (4887 in 2WX mode)
Presets 288-293	4-Way + DOWNFILL (4887A DF) + OFFSTAGE FILL (4887A in 2WX mode)
Presets 294-299	4-Way + DOWNFILL (4887 DF) + DISTRIBUTED FILL (4887 in 2W mode)
Presets 300-305	4-Way + DOWNFILL (4887A DF) + DISTRIBUTED FILL (4887A in 2W mode)