



VERTEC VT4888 V4 PRESETS

BSS FDS-366 Omnidrive Compact Plus

		INPUT A	INPUT B	INPUT C			
3-WAY STEREO	PRESET	OUT 1	OUT 2	OUT 3	OUT 4	OUT 5	OUT 6
USER	1	AUX (FULLRANGE)	AUX (FULLRANGE)	AUX (FULLRANGE)	AUX (FULLRANGE)	AUX (FULLRANGE)	AUX (FULLRANGE)
4888 3WX	2	4888 LOW	4888 MID	4888 HI	4888 LOW	4888 MID	4888 HI
4-WAY + AUX	PRESET	OUT 1	OUT 2	OUT 3	OUT 4	OUT 5	OUT 6
88 81A X	3	4881A	4888 LOW	4888 MID	4888 HI	AUX (FULLRANGE)	AUX (FULLRANGE)
88 81A 60	4	4881A	4888 LOW	4888 MID	4888 HI	AUX (FULLRANGE)	AUX (FULLRANGE)
88 81A 80	5	4881A	4888 LOW	4888 MID	4888 HI	AUX (FULLRANGE)	AUX (FULLRANGE)
88 82 X	6	4882	4888 LOW	4888 MID	4888 HI	AUX (FULLRANGE)	AUX (FULLRANGE)
88 82 60	7	4882	4888 LOW	4888 MID	4888 HI	AUX (FULLRANGE)	AUX (FULLRANGE)
88 82 80	8	4882	4888 LOW	4888 MID	4888 HI	AUX (FULLRANGE)	AUX (FULLRANGE)
88 80 X	9	4880	4888 LOW	4888 MID	4888 HI	AUX (FULLRANGE)	AUX (FULLRANGE)
88 80 60	10	4880	4888 LOW	4888 MID	4888 HI	AUX (FULLRANGE)	AUX (FULLRANGE)
88 80 80	11	4880	4888 LOW	4888 MID	4888 HI	AUX (FULLRANGE)	AUX (FULLRANGE)
88 80A X	12	4880A	4888 LOW	4888 MID	4888 HI	AUX (FULLRANGE)	AUX (FULLRANGE)
88 80A 60	13	4880A	4888 LOW	4888 MID	4888 HI	AUX (FULLRANGE)	AUX (FULLRANGE)
88 80A 80	14	4880A	4888 LOW	4888 MID	4888 HI	AUX (FULLRANGE)	AUX (FULLRANGE)
4-WAY + 4887A OFFSTAGE FILL (2WX)	PRESET	OUT 1	OUT 2	OUT 3	OUT 4	OUT 5	OUT 6
88 82 X 2X	15	4882	4888 LOW	4888 MID	4888 HI	4887A LOW 2WX	4887A MID/HI 2WX
88 82 60 2X	16	4882	4888 LOW	4888 MID	4888 HI	4887A LOW 2WX	4887A MID/HI 2WX
88 82 80 2X	17	4882	4888 LOW	4888 MID	4888 HI	4887A LOW 2WX	4887A MID/HI 2WX
88 80 X 2X	18	4880	4888 LOW	4888 MID	4888 HI	4887A LOW 2WX	4887A MID/HI 2WX
88 80 60 2X	19	4880	4888 LOW	4888 MID	4888 HI	4887A LOW 2WX	4887A MID/HI 2WX
88 80 80 2X	20	4880	4888 LOW	4888 MID	4888 HI	4887A LOW 2WX	4887A MID/HI 2WX
88 80A X 2X	21	4880A	4888 LOW	4888 MID	4888 HI	4887A LOW 2WX	4887A MID/HI 2WX
88 8A 60 2X	22	4880A	4888 LOW	4888 MID	4888 HI	4887A LOW 2WX	4887A MID/HI 2WX
88 8A 80 2X	23	4880A	4888 LOW	4888 MID	4888 HI	4887A LOW 2WX	4887A MID/HI 2WX
4-WAY + 4887A DISTRIBUTED FILL (2W)	PRESET	OUT 1	OUT 2	OUT 3	OUT 4	OUT 5	OUT 6
88 82 X 2W	24	4882	4888 LOW	4888 MID	4888 HI	4887A LOW 2W	4887A MID/HI 2W
88 82 60 2W	25	4882	4888 LOW	4888 MID	4888 HI	4887A LOW 2W	4887A MID/HI 2W
88 82 80 2W	26	4882	4888 LOW	4888 MID	4888 HI	4887A LOW 2W	4887A MID/HI 2W
88 80 X 2W	27	4880	4888 LOW	4888 MID	4888 HI	4887A LOW 2W	4887A MID/HI 2W
88 80 60 2W	28	4880	4888 LOW	4888 MID	4888 HI	4887A LOW 2W	4887A MID/HI 2W
88 80 80 2W	29	4880	4888 LOW	4888 MID	4888 HI	4887A LOW 2W	4887A MID/HI 2W
88 80A X 2W	30	4880A	4888 LOW	4888 MID	4888 HI	4887A LOW 2W	4887A MID/HI 2W
88 8A 60 2W	31	4880A	4888 LOW	4888 MID	4888 HI	4887A LOW 2W	4887A MID/HI 2W
88 8A 80 2W	32	4880A	4888 LOW	4888 MID	4888 HI	4887A LOW 2W	4887A MID/HI 2W
5-WAY + AUX	PRESET	OUT 1	OUT 2	OUT 3	OUT 4	OUT 5	OUT 6
88 82 80 X	33	4880	4882	4888 LOW	4888 MID	4888 HI	AUX (FULLRANGE)
88 82 80 60	34	4880	4882	4888 LOW	4888 MID	4888 HI	AUX (FULLRANGE)
88 82 80A X	35	4880A	4882	4888 LOW	4888 MID	4888 HI	AUX (FULLRANGE)
88 82 8A 60	36	4880A	4882	4888 LOW	4888 MID	4888 HI	AUX (FULLRANGE)

NOTES:

Presets 2	Stereo 3-Way Preset (extended LF Response - low section HPF unlocked)
* Presets 3-14	4-Way Presets for 4881A, 4882, 4880 or 4880A + VT4888 + Aux Outputs 5/6
* Presets 15-23	4-Way Presets for 4882, 4880 or 4880A + VT4888 + Center Cluster / Offstage Fill (4887A in 2WX mode)
* Presets 24-32	4-Way Presets for 4882, 4880 or 4880A + VT4888 + Distributed Fill (4887A in 2W mode)
* Presets 33-36	5-Way Presets for Ground Stacked 4880 or 4880A + Flown VT4888 / VT4882 + AUX

* FOR AUX SUB DRIVE USE UTILS/SOURCE TO SELECT DESIRED INPUT