



VERTEC DRIVEPACK V4 PRESETS

VT4881ADP-CN



DEVICE FILE NAME: V4 Rev A.VT4881ADP-CN.device

FACTORY MEMORY	PRESET	DESCRIPTION
VT4881ADP-CN 4887A 60	1	VT4881ADP (60 Hz LPF) for use with VT4887A or VT4887ADP (60 preset)
VT4881ADP-CN 4887A 80	2	VT4881ADP (80 Hz LPF) for use with VT4887A or VT4887ADP (80 preset)
VT4881ADP-CN 4887A 100	3	VT4881ADP (100 Hz LPF) for use with VT4887A or VT4887ADP (100 preset)

FACTORY MEMORY	PRESET	DESCRIPTION
VT4881ADP-CN 4888 X	4	VT4881ADP (80 Hz LPF, NEGATIVE POLARITY) for use with VT4888 or VT4888DP (X preset)
VT4881ADP-CN 4888 60	5	VT4881ADP (60 Hz LPF) for use with VT4888 or VT4888DP (60 preset)
VT4881ADP-CN 4888 80	6	VT4881ADP (80 Hz LPF) for use with VT4888 or VT4888DP (80 preset)

FACTORY MEMORY	PRESET	DESCRIPTION
VT4881ADP-CN 4889 X	6	VT4881ADP (80 Hz LPF, NEGATIVE POLARITY) for use with VT4889, VT4889-1 or VT4889ADP (X preset)
VT4881ADP-CN 4889 60	7	VT4881ADP (60 Hz LPF) for use with VT4889, VT4889-1 or VT4889ADP (60 preset)
VT4881ADP-CN 4889 80	8	VT4881ADP (80 Hz LPF) for use with VT4889, VT4889-1 or VT4889ADP (80 preset)

FACTORY MEMORY	PRESET	DESCRIPTION
VT4881ADP-CN 120	10	VT4881ADP 120 Hz LPF (for use with outboard DSP)

NOTE: REAR PANEL BUTTON SUB FILTER OFF / ON OPERATION TOGGLES BETWEEN PRESET 10 (OFF) AND PRESET 2 (ON)